

NOVASET – LINE KIT

INSTRUCTIONS

Necessary equipment:

- Line kit
- Water bucket
- Brushing roller (e. g. paint brush roller)
- Warm water
- Watering can with a fine sprinkler

Before placing the lines, it must be the bottom ice heave and even. Suitable temperature is -2 to -20 degrees Celsius (29 to -5 F).

The lines and the points of the face-off lay on the place according to the rules and on the even ice layer. Soak the brush roller to the warm water and then cross with it the lines, allowing the line absorbs water so that it freezes upon the ice.

After first freezing we recommend to sprinkle again the lines with the watering can to create the continuous ice layer above them. After its freezing it is possible to create other ice layers in the standard way on the whole playing field.

After melting you can't use the lines again.